

Equipment Configuration Checklist, integrated with MAPP (credit/debit)

	Paper Check w/o Chk Rdr	Paper Check w/ Chk Rdr	Check Conversion w/ Imager (guar only)	Check Conversion w/ Chk Rdr (verify only)	Check21 w/Imager	Gift Card	Loyalty
TechTrex							
PrimeTrex	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f	Yes	Yes
Notes:	Franking option available with the RDM EC6004f/EC6005f/EC6014f. ConverTrex needed if using IP with a PrimeTrex.						
PrimeTrex IP ("PAI-Trex")	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f	Mini MICR	EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f	Yes	Yes
Notes:	Franking option available with the RDM EC6004f/EC6005f/EC6014f. PrimeTrex IP and PAI Trex do not need ConverTrex for IP						
PrimeTrex One ("PAI-Trex One")	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Notes:	PrimeTrex One is an all-in-one terminal, with an in-built imager and capable of dial-up or IP communication Terminal can only autoseettle one application						
PrimeTrex S ("PAI-Trex S")	Yes	Yes Mini MICR	Yes EC6014i/EC6014f	Yes Mini MICR	Yes EC6014i/EC6014f	Yes	Yes
Notes:	Franking option available with the RDM EC6014f						
VeriFone							
Tranz 330 / 380 / 460	Yes	Mini MICR	No	No	No	No	No
Notes:	See Stand Alone SPS checklist for conversion and gift possibilities.						
Tranz 380x2	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f	Mini MICR	No	Yes	No
Notes:	Franking option available with the RDM EC6004f/EC6005f/EC6014f.						
Omni 3200	Yes	Mini MICR	No	No	No	No	No
Notes:	Terminal must be loaded with credit application prior to adding Paper Check service						
Omni 3730 / 3730LE / 3740 / 3750	Yes	Mini MICR CR600	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f EC6011* EC7011* EC7014f CR1000 MICR Imager	Mini MICR CR600	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f EC6011* EC7011* EC7014f CR1000 MICR Imager	Yes	Yes
Notes:	* RDM EC6011 and EC7011 have no modem and require the terminal to have an IP connection to upload 3730 model does not support dual comm (IP) and has limited memory 3730LE model does not support dual comm (IP) and is limited to a single application If integrating credit, debit, check and gift/loyalty, terminal must be 4 MB minimum, preferably 6 MB IP or Dual Comm needed if loading an IP Application Imagers require an analog phone line for the uploading of images unless uploading via IP. Franking option available with the RDM EC6004f/EC6005f/EC6014f/EC7014f If using the Magtek MICR Imager it must be ordered or configured to 19200 bps.						
Vx510 / Vx510LE / Vx570 / Vx610	Yes	Mini MICR CR600	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f EC6011* EC7011* EC7014f CR1000 MICR Imager	Mini MICR CR600	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f EC6011* EC7011* EC7014f CR1000 MICR Imager	Yes	Yes
Notes:	* RDM EC6011 and EC7011 have no modem and require the terminal to have an IP connection to upload Vx510LE model does not support dual comm (IP) and is limited to a single application If integrating credit, debit, check and gift/loyalty, terminal must be 4 MB minimum, preferably 6 MB IP or Dual Comm needed if loading an IP Application Vx610 wireless capability is dependent on the SIM card installed and may require a physical analog telephone or IP connection Imagers require an analog phone line for the uploading of images unless uploading via IP. Franking option available with the RDM EC6004f/EC6005f/EC6014f/EC7014f If using the Magtek MICR Imager it must be ordered or configured to 19200 bps.						
Vx520 / Vx670	Yes	Mini MICR CR600	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f EC6011* EC7011* EC7014f CR1000 MICR Imager	Mini MICR CR600	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f EC6011* EC7011* EC7014f CR1000 MICR Imager	Yes	Yes
Notes:	* RDM EC6011 and EC7011 have no modem and require the terminal to have an IP connection to upload						
IMPORTANT:	Security certificates are required before downloading (unless standalone) Certificates must be provided by the terminal owner (first downloader) before installation can occur Certificates remain in terminal after clearing, and must be removed by the originator by special process						
Notes:	IP or Dual Comm needed if loading an IP Application Vx670 wireless capability is dependent on the SIM card installed and may require a physical analog telephone connection Imagers require an analog phone line for the uploading of images unless uploading via IP. Franking option available with the RDM EC6004f/EC6005f/EC6014f/EC7014f If using the Magtek MICR Imager it must be ordered or configured to 19200 bps.						
VeriFone (Lipman)							
Nurit 2085 / 2085+ / 3000 / 3020	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	No	Yes	Yes
Notes:	Requires a NOS 7 upgrade unless Paper Check 3000 model can not upgrade to NOS 7; Only Paper Check service or standalone is allowed Franking option available with the RDM EC6004f/EC6014f only Credit Card support is downgraded to Class B						
Nurit 3010 / 8000	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	No	Yes	Yes
Notes:	Requires a NOS 7 upgrade unless Paper Check Only models 10 and 12 of the 3010 can be upgraded to NOS 7 Nurit 8000 does not have ability to connect a check reader/imager, unless connected to base. Must have an physical analog telephone connection. Franking option available with the RDM EC6004f/EC6014f only Credit Card support is downgraded to Class B						
Nurit 8320 / 8400	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	No	Yes	Yes
Notes:	8320 Model 14A is a proprietary terminal, SPS cannot load it. The acquirer must add SPS services Franking option available with the RDM EC6004f/EC6014f only Credit Card support is downgraded to Class B						
Equinox (Hypercom)							
T4100	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Yes	Yes
Notes:	Franking option available with the RDM EC6004f/EC6005f/EC6014f.						
T4205 / T4210 / T4220 / T4230	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Yes	Yes
Notes:	T4205 and T4210 are Dial-up only Franking option available with the RDM EC6004f/EC6005f/EC6014f. T4230 wireless capability is dependent on the SIM card installed and may require a physical analog telephone or IP connection						
T7p / T77 / Plus	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	No	Yes	No
Notes:	Terminal has reached End-of-Life SPS can build a dnld file if provided VAR for other services. Franking option available with the RDM EC6004f/EC6005f/EC6014f Must be 512K or higher If using the Magtek MICR Imager it must be ordered with or configured to 9600 bps						
ICE 5500	Yes	Mini MICR	EC5003i / EC5004i EC6004i / EC6005i EC6004f/EC6005f EC6014i/EC6014f MICR Imager	Mini MICR	No	Yes	No
Notes:	Terminal has reached End-of-Life SPS can build a dnld file if provided VAR for other services. Franking option available with the RDM EC6004f/EC6005f/EC6014f Must be 512K or higher If using the Magtek MICR Imager it must be ordered with or configured to 9600 bps						
ICE 5700	No	Yes	No	Yes	No	Yes	No
Notes:	Terminal has in-built End-of-Life Terminal has in-built check reader SPS can build a dnld file if provided VAR for other services. Must be 512K or higher						
Ingenico							
Elite 510 / 512 / 710 / 712	Yes	enCheck 2500	enCheck 2600	enCheck 2500	No	Yes	No
Notes:	If a proprietary credit card app., the cc comp. must provide the terminal password in order to download any SPS app.						